

7. Changing the Date & Time

Follow these steps to set the date and time

1. Connect the PenCam to your PC
2. Create a .txt file with Windows Notepad
3. Type the date & time in the following format
YYYYMMDDHHMMSS, ex. 20081027162500
(year, month, day, hour, minutes, seconds)
4. Save the file as **SysTime.txt** and place in the root directory of the PenCam
5. Remove from the computer and turn on the PenCam

NOTE: **SysTime.txt** is a case sensitive file and must be named exactly as shown

8. Miscellaneous Features

The PenCam can be used as a USB removeable storage disk
If the PenCam locks up, use a pin and push the reset button
Software can be downloaded from www.swannsecurity.com

9. Technical Specifications

Video

Video Format: AVI
Resolution: 352 x 288
Video File Size: >500KB per min

Recording

Recording Mode: Manual Recording, Continuous
Record Time: 3 Hours
Audio Recording: Yes
Audio Range: 1m (3ft)

General

Operating System: Windows XP, Vista
Internal Memory: 2GB
Backup Type: USB
Battery Type: Rechargeable Lithium-ion
Charging: USB adapter Cable
Battery Charge: Approximately 90 mins
Dimensions: 150mm x 15mm x 15mm
5.9" x 0.6" x 0.6"
Weight: 30g, 1oz



If this product does not work when you first plug it in or you have any concerns, don't take it back to the store!

Use this Quick Start Guide or
Visit www.swannsecurity.com/help

Contact our expert Tech Support Team...
Email - tech@swannsecurity.com

United States * 1-800-627-2799
1-877-274-3695

Sun 2pm-10pm, Mon-Thurs 6am-10pm
Fri 6am-2pm (PT)

Australia* 1300 138 324
Mon 9am-5pm, Tues-Fri 1am-5pm
Sat 1am-9am (AET)

New Zealand* 0800 479 266
Mon 11am-7pm, Tues-Fri 3am-7am
Sat 3am-11am (NZST)

International* +61 3 8412 4610

*Hours vary during daylight savings times
Consult www.worldtimeserver.com for the current Melbourne, Australia time

FCC WARNING STATEMENT:

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation

NOTE: All jurisdictions have specific laws and regulations relating to the use of cameras. Before using any camera for any purpose it is the buyer's responsibility to be aware of all applicable laws and regulations that prohibit or limit the use of cameras and to comply with the applicable laws and regulations.



PenCam Recorder




Quick Start Guide

SW234-PC2

1. Package Contents

- PenCam Camera
- USB Adapter Cable
- Manual

2. PenCam Layout



3. Powering the PenCam On/Off

To power on the PenCam press and hold the top Power Button until the orange light appears. After a few seconds the PenCam will automatically begin recording indicated by the blue light



To turn off the PenCam push and hold the Power button until the light turns off

4. Recording Video

1. Power on the PenCam as in step 3. When first turned on the PenCam will automatically begin recording indicated by the solid blue light
2. Push the top button to stop a recording
3. Push the top button again to begin another recording

NOTE: Allow several seconds for the PenCam to finish processing before starting another recording



Note: To prevent loss of footage, ensure the camera has stopped recording and the light is orange before powering the PenCam off

5. Charging the PenCam

The PenCam has a built in lithium-ion battery that provides approximately 90 minutes of power when fully charged



Charge the PenCam by connecting the USB adapter to the hidden USB connector inside the PenCam, then connect the USB adapter to an available USB port on your computer



Charging time for the PenCam is 2 hours - Before using for the first time be sure to charge for full 2 hours

NOTE: If the battery loses charge while recording the orange light will begin to flash rapidly and save the current recording before shutting down. Charge the PenCam

6. Downloading Videos to PC

When the PenCam is connected to a PC, Windows XP and Vista will automatically recognize the device and install the correct drivers

Navigate to the Removeable Disk in My Computer to view, copy or delete the files

Playback video recordings on your PC with free media players such as VLC, winDVD, powerDVD etc. capable of decoding H263 format AVI files.

NOTE: If you are unable to view videos on your PC, install the codec pack software named **klcodec417s.exe** stored on the PenCam or download from www.swannsecurity.com